


DWM 10000 HD



1. Controls
2. Screw
3. Motor cover
4. Bearing
5. Brush-holder/brushes
6. Rotor
7. Stator
8. Bearing
9. Screw
10. Assembly foot
11. Slide bearing
12. Brake driver
13. Dynamic brake
14. Drum
15. Beam
16. Drive axle
17. Slide bearing
18. Screw
19. Beam bolt
20. Assembly foot
21. Gasket
22. 3rd stage of the gear
23. Washer
24. 2nd stage of the gear
25. Annular gear track
26. Gear housing
27. In/Out switch
28. Annular gear track
29. 1st stage of the gear
30. Drive mode
31. Gear cover
32. Screw