


DWH 15000 HD



- 1.Screw
2. Motor radiator
- 3.Spring washer
4. Rotor bearing
5. Brushes/ brush holder
6. O-ring
- 7.Motor stator
- 8.Rotor
- 9.Rotor bearing
- 10.Assembly foot
- 11.Gasket
- 12.Slide bearing
- 13.Lip seal
- 14.Brake driver
- 15.Dynamic brake
- 16.Beam
- 17.Beam bolt
- 18.Drum
- 19.Lip seal
- 20.Slide bearing
- 21 Gasket
- 22.Screw assembly feet
- 23.Assembly foot
- 24.Gasket
- 25 3nd stage of the gear
26. Housing/ annular gear track
27. O-ring
- 28.2nd stage of the gear
- 29 1st stage of the gear
- 30.Annular gear track
- 31 Drive mode
- 32.Gear housing
- 33.In/Out switch
- 34.In/Out handle counter - screw
- 35.Screw